



BALANCE WEIGHTS FOR PASSENGER CARS

Lead balance weights for passenger cars have been discontinued due to new legislation (1st July 05). In order to comply with this legislation, Schrader now offer a range of ZINC ALLOY and STEEL weights.

BALANCE WEIGHTS FOR TRUCKS

A range of weights for the balance of truck rims in steel and alloy, with springs or adhesive.

TRUCKS BALANCING BEADS

Due to centrifugal force, the beads automatically balance the complete wheel assembly in all wheel position on both trucks and trailers.

